


# Parts Manual

Mfg. No: 245432-0135-H1



<b>Model Components</b>	<b>Page</b>
Air Cleaner, Brackets. ....	4
Blower Housing, Regulator, Wires, Rocker Switch. ....	6
Carburetor. ....	8
Carburetor Overhaul Kit, Engine/Valve Gasket Sets. ....	10
Carburetor Overhaul Kits, Engine/Valve Gasket Sets. ....	12
Carburetor, Carburetor Insulators. ....	14
Carburetors, Intake Manifold. ....	16
Control Brackets, Springs, Link. ....	18
Control Panels. ....	20
Crankcase Cover, Counterweight, Dipstick. ....	22
Crankcase Cover, Dipstick Tubes, Counterweight. ....	24
Cylinder Head, Valve Cover, Spark Plug. ....	28
Cylinder, Governor Lever, Shields, Carbon Canister. ....	30
Cylinder, Oil Sensor, Governor Control Lever, Manuals. ....	32
Electric Starter, Starter Solenoid. ....	34
Flywheel, Alternator, Magneto Armature, Regulator. ....	36
Flywheels, Harness, Alternator, Key Switch, Coil. ....	38
Fuel Tank, Fuel Pump, Fuel Hoses, Fuel Filter. ....	40
Fuel Tank, Fuel Shut Off Valve, Carbon Canister. ....	42
Lo Mount Muffler. ....	44
Muffler, Spark Arrestors, Muffler Deflectors. ....	46
Panel Air Cleaner. ....	52
Piston/Ring, Crankshaft, Camshaft, Connecting Rod. ....	54
Piston/Ring, Crankshafts, Connecting Rod. ....	56
Replacement Engine. ....	58
Rewind Starters. ....	59
Springs, Control Brackets, Electro Magnet. ....	61




## ***Air Cleaner, Brackets***

REF NO	PART NO	QTY	DESCRIPTION
11	710115		Tube-Breather
53	710556		Stud -(Carburetor) (M6x100mm)
185	710068		Nut -(Air Cleaner Base)
235A	711956		Shield-Fuel Spray
425	694515		Screw -(Air Cleaner Cover)
717	711951		Bracket-Air Cleaner
717A	711952		Bracket-Air Cleaner
875A	711955		Base-Air Cleaner
961	711953		Screw -(Air Cleaner Bracket)
968A	711954		Cover-Air Cleaner

Not For  
Reproduction








# Blower Housing, Regulator, Wires, Rocker Switch

Mfg. No: 245432-0135-H1



## ***Blower Housing, Regulator, Wires, Rocker Switch***




REF NO	PART NO	QTY	DESCRIPTION
304	711286		Housing-Blower -(Electric Start)
304	711937		Housing-Blower -(Rewind Start)
305	710023		Screw -(Blower Housing)
318A	710023		Screw -(Mounting Bracket)
347A	712170		Switch-Rocker
356	710120		Wire-Stop
356A	711839		Wire-Stop -(Rocker Switch)
356B	711840		Wire-Stop -(Rocker Switch)
367	712559		Screw -(Wire Clip) (M6x12mm)
501	595154		Regulator
526	710057		Screw -(Regulator)
557	710781		Screw -(Oil Gard Module)
563	710074		Screw -(Debris Screen Guard)
729	710083		Clip-Wire
774	710023		Screw -(Stop Wire)
949	690475		Guard-Debris Screen
1053	710305		Module-Oil Gard
1129	710978		Washer -(Oil Gard Module)









## Carburetor

REF NO	PART NO	QTY	DESCRIPTION
51	710559		Gasket-Intake
93	690602		Bushing-Throttle Shaft
94B	716236		Kit-Idle Mixture
95	691636		Screw -(Throttle Valve)
98	495800		Kit-Idle Speed
104	690525		Pin-Float Hinge
105	231855S		Valve-Float Needle
105A	712001		Valve-Float Needle -(Carburetor I.D. Number 715744)
106	690577		Seat-Inlet
108	691227		Valve-Choke
122	715377		Spacer-Carburetor
125	715783		Carburetor -(Carburetor I.D. Number 715744)
127	695005		Plug-Welch
130	690468		Valve-Throttle
131B	712544		Kit-Throttle Shaft
133C	712543		Float-Carburetor
137	281165S		Gasket-Float Bowl
141C	712545		Kit-Choke Shaft
142	691462		Nozzle-Carburetor -(Standard)
142A	712002		Nozzle-Carburetor -(Carburetor I.D. Number 715744)
276	692255		Washer-Sealing
633	690597		Seal-Choke/Throttle Shaft -(Choke Shaft)
692	691301		Spring-Detent
950	691657		Screw-Float Bowl
987	691326		Seal-Throttle Shaft
1091	691333		Cap-Limiter



## Carburetor Overhaul Kit, Engine/Valve Gasket Sets

REF NO	PART NO	QTY	DESCRIPTION
3	291675S		Seal-Oil -(Magneto Side)
7	710539		Gasket-Cylinder Head
12	710378		Gasket-Crankcase
20	291675S		Seal-Oil -(PTO Side)
51	710559		Gasket-Intake
93	690602		Bushing-Throttle Shaft
104	690525		Pin-Float Hinge
105	231855S		Valve-Float Needle
106	690577		Seat-Inlet
121	715707		Kit-Carburetor Overhaul
127	695005		Plug-Welch
137	281165S		Gasket-Float Bowl
276	692255		Washer-Sealing
358	715383		Gasket Set-Engine
464	710069		Seal-O Ring -(Fuel Shut-off Valve)
631	710004		Washer -(Oil Drain Plug)
633	690597		Seal-Choke/Throttle Shaft -(Choke Shaft)
691	710055		Seal-Governor Shaft
696	710091		Seal-O Ring -(Oil Sensor)
842A	710218		Seal-O Ring -(Dipstick Tube)
883	711182		Gasket-Exhaust
883A	710250		Gasket-Exhaust
883B	711181		Gasket-Exhaust
987	691326		Seal-Throttle Shaft
1022	710377		Gasket-Rocker Cover
1095	715386		Gasket Set-Valve




## ***Carburetor Overhaul Kits, Engine/Valve Gasket Sets***

---






REF NO	PART NO	QTY	DESCRIPTION
12	710378		Gasket-Crankcase
163B	712535		Gasket-Air Cleaner
868A	711634		Seal-Valve

---

Not For  
Reproduction



692A






## *Carburetor, Carburetor Insulators*

---

REF NO	PART NO	QTY	DESCRIPTION
975B	716546		Bowl-Float

---

Not For  
Reproduction








## ***Carburetors, Intake Manifold***

REF NO	PART NO	QTY	DESCRIPTION
51	710559		Gasket-Intake
105A	712001		Valve-Float Needle -(Carburetor I.D. Number 715744)
122	715377		Spacer-Carburetor
137	281165S		Gasket-Float Bowl
142B	711995		Nozzle-Carburetor -(Standard)
276	692255		Washer-Sealing

Not For  
Reproduction



Not For  
Reproduction








***Control Brackets, Springs, Link***

---

REF NO	PART NO	QTY	DESCRIPTION
163B	712535		Gasket-Air Cleaner
209A	712532		Spring-Governor

---


Not For  
Reproduction



## Control Panels

REF NO	PART NO	QTY	DESCRIPTION
281	711765		Panel-Control -(Includes Labels)
281A	711990		Panel-Control -(Includes Labels)
281B	710919		Panel-Control -Used Before Code Date 03070100
281C	710571		Panel-Control -Used Before Code Date 03070100
281C	711959		Panel-Control -Used After Code Date 03063000
281B	711991		Panel-Control -Used After Code Date 03063000
663	710234		Screw -(Control Panel)
663A	710095		Screw -(Control Panel) (M6x30mm)
663B	711249		Screw -(Control Panel) (Self Tap)
663C	712177		Screw -(Control Panel) (M6x90mm)

Not For  
Reproduction




## *Crankcase Cover, Counterweight, Dipstick*

---

REF NO	PART NO	QTY	DESCRIPTION
12	710378		Gasket-Crankcase
17A	710482		Bearing-Ball

---


Not For  
Reproduction






## Crankcase Cover, Dipstick Tubes, Counterweight

REF NO	PART NO	QTY	DESCRIPTION
12	710378		Gasket-Crankcase
17	710528		Bearing-Ball
17A	710482		Bearing-Ball
18	715358		Cover-Crankcase
20	291675S		Seal-Oil -(PTO Side)
21	493668		Cap-Oil Fill
22	710032		Screw -(Crankcase Cover/Sump) (M8x30mm)
22A	710306		Screw -(Crankcase Cover/Sump)
219	715696		Gear-Governor -(Do Not Use Washer) -Used Before Code Date 04040100
219	715727		Gear-Governor -Used After Code Date 04033100
220	710545		Washer -(Governor Gear)
221	710872		Cup-Governor
225	710028		Shaft-Governor Gear
287	710234		Screw -(Dipstick Tube)
287A	710023		Screw -(Dipstick Tube)
287B	806660		Screw -(Dipstick Tube) (M8x18mm)
523	693175		Dipstick
523A	710817		Dipstick
524	-----		Seal-Dipstick Tube -(NO LONGER AVAILABLE)
524B	693172		Seal-Dipstick Tube
525A	693173		Tube-Dipstick
527	710100		Clamp-Tube
718	710005		Pin-Locating
758	712123		Counterweight
842	691870		Seal-O Ring -(Dipstick Tube)
842A	710218		Seal-O Ring -(Dipstick Tube)
847	710543		Dipstick/Tube Assembly



Not For  
Reproduction




## ***Cylinder Head, Valve Cover, Spark Plug***



REF NO	PART NO	QTY	DESCRIPTION
5A	716160		Head-Cylinder
35A	712537		Spring-Valve -(Intake) (Qty. 2)
36A	712537		Spring-Valve -(Exhaust) (Qty. 2)
42	716520		Keeper-Valve
337A	712175		Plug-Spark
383	19576S		WRENCH, Spark Plug
635A	712030		Boot-Spark Plug
868A	711634		Seal-Valve
1023A	716522		Cover-Rocker
1029A	716521		Arm-Rocker

Not For  
Reproduction

718 




914 



## Cylinder Head, Valve Cover, Spark Plug

REF NO	PART NO	QTY	DESCRIPTION
7	710539		Gasket-Cylinder Head
13	710204		Screw -(Cylinder Head) (M10x65mm)
33	716079		Valve-Exhaust
34	716080		Valve-Intake
42	716520		Keeper-Valve
45	710530		Tappet-Valve
53	710556		Stud -(Carburetor) (M6x100mm)
192	715372		Adjuster-Rocker Arm
293	710538		Screw -(Rocker Arm Shaft) (M6x20mm)
296	710099		Stud -(Muffler)
383	19576S		WRENCH, Spark Plug
718	710005		Pin-Locating
773	710537		Retainer -(Rocker Arm Shaft)
914	710023		Screw -(Rocker Cover) (M6x12mm)
1022	710377		Gasket-Rocker Cover
1026	710373		Rod-Push -(Intake and Exhaust)
1031	710533		Shaft-Rocker Arm
1060	710535		Spring-Rocker Shaft



## *Cylinder, Governor Lever, Shields, Carbon Canister*

---

REF NO	PART NO	QTY	DESCRIPTION
1A	716540		Cylinder Assembly
17A	710482		Bearing-Ball









---

Not For  
Reproduction

1036

1319

1330




Not For Reproduction



## Cylinder, Oil Sensor, Governor Control Lever, Manuals



REF NO	PART NO	QTY	DESCRIPTION
1	715095		Cylinder Assembly
3	291675S		Seal-Oil -(Magneto Side)
15	715000		Plug-Oil Drain
17	710528		Bearing-Ball
17A	710482		Bearing-Ball
227	710561		Lever-Governor Control
306	710242		Shield-Cylinder
307	710023		Screw -(Cylinder Shield)
404	710058		Washer -(Governor Crank)
505	710059		Nut -(Governor Control Lever)
586	710068		Nut -(Oil Sensor)
586	712588		Nut -(Oil Sensor)
614	710056		Pin-Cotter
616	710560		Crank-Governor
631	710004		Washer -(Oil Drain Plug)
691	710055		Seal-Governor Shaft
696	710091		Seal-O Ring -(Oil Sensor)
718	710005		Pin-Locating
725	710568		Shield-Heat
728	710023		Screw -(Heat Shield)
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1052A	712556		Sensor-Oil
1319	794467		LABEL, Warning
1330	272147		Repair Manual





## ***Electric Starter, Starter Solenoid***

<b>REF NO</b>	<b>PART NO</b>	<b>QTY</b>	<b>DESCRIPTION</b>
309	715208		Motor-Starter -(Steel Pinion)
310	710589		Screw -(Starter Motor)
413	710081		Nut -(Starter Motor)
493C	691177		BRACKET, Mounting -(Starter Solenoid)
510	496881		Drive-Starter
555	810059		Screw -(Starter Solenoid)
683	691029		NUT -(Starter Solenoid)
697	710348		Screw -(Starter Motor) (Drive Cap)
813	690635		CLAMP
893	712588		Nut -(Starter Solenoid)
920	691656		SOLENOID, Starter
1051	691124		Ring-Retaining

Not For  
Reproduction



1119A




334A

## *Flywheel, Alternator, Magneto Armature, Regulator*

---

REF NO	PART NO	QTY	DESCRIPTION
333A	712447		Armature-Magneto
526	710057		Screw -(Regulator)
578B	712557		Wire Assembly
635A	712030		Boot-Spark Plug
1005A	712449		Fan-Flywheel
1006A	712450		Retainer-Fan




Not For  
Reproduction







## ***Flywheels, Harness, Alternator, Key Switch, Coil***

<b>REF NO</b>	<b>PART NO</b>	<b>QTY</b>	<b>DESCRIPTION</b>
23	715265		Flywheel
23A	715258		Flywheel
332	710345		Nut -(Flywheel)
334	690938		Screw -(Magneto Armature)
356E	710324		Wire-Stop
455	710588		Cup-Flywheel
474	715798		Alternator
493B	710575		Bracket-Mounting -(Key Switch)
500	691086		WASHER -(Key Switch)
664	691087		NUT -(Key Switch)
729B	710046		Clip-Wire
789	710576		Harness-Wiring
878	710417		Harness-Alternator
892	692318		Switch-Key
934	710550		Screw -(Fan Retainer)
983	692362		Light-Indicator
990	691959		SET, Key
1119	690938		Screw -(Alternator)


Not For Reproduction



601A



668











240

240A



## Fuel Tank, Fuel Pump, Fuel Hoses, Fuel Filter


REF NO	PART NO	QTY	DESCRIPTION
38	710160		Screw -(Fuel Shut Off Valve) (M6x25mm)
190	710047		Screw -(Fuel Tank) (M6x30mm)
240	298090S		Filter-Fuel
240A	691035		FILTER, Fuel
246	710070		Bowl-Fuel Filter
315	710072		Seal-O Ring -(Fuel Filter Bowl)
387	715303		Pump-Fuel
387A	808656		PUMP, Fuel
464	710069		Seal-O Ring -(Fuel Shut-off Valve)
628	710248		Screw -(Fuel Pump Bracket) (M6x16mm)
628A	710234		Screw -(Fuel Pump Bracket)
670	710508		Spacer-Fuel Tank
705	710509		Nut -(Fuel Tank)
788	710917		Bracket-Fuel Pump
918A	716124		Hose-Vacuum -(Cut To Required Length)
958	715224		Valve-Fuel Shut Off
1121	710068		Nut -(Fuel Pump Bracket)



## ***Fuel Tank, Fuel Shut Off Valve, Carbon Canister***

REF NO	PART NO	QTY	DESCRIPTION
182A	712549		Bracket-Fuel Tank
187D	712534		Line-Fuel
210B	712476		Strainer-Fuel
360	710068		Nut -(Fuel Tank Bracket)
601F	712552		Clamp-Hose -(Fuel Tank Outlet)
668A	712550		Spacer -(Fuel Tank Bracket)
674B	712551		Screw -(Fuel Tank Bracket) (M6x16mm)
957A	712548		Cap-Fuel Tank
972A	712547		Tank-Fuel









Not For  
Reproduction



## Lo Mount Muffler


REF NO	PART NO	QTY	DESCRIPTION
298	710090		Locknut-Muffler/Elbow
300A	715600		Muffler -(Low Mount)
303A	715604		Elbow-Exhaust -(Low Mount)
832A	710791		Guard-Muffler -(Low Mount)(Front)
832B	710792		Guard-Muffler -(Low Mount)(Rear)
836	710074		Screw -(Muffler Guard) (M6x8mm)
883	711182		Gasket-Exhaust
883A	710250		Gasket-Exhaust
1057A	710331		Screen-Outlet

Not For  
Reproduction



## Muffler, Spark Arrestors, Muffler Deflectors

REF NO	PART NO	QTY	DESCRIPTION
296	710099		Stud -(Muffler)
298	710090		Locknut-Muffler/Elbow
300	715894		Muffler
303	715824		Elbow-Exhaust
346	690661		SCREW -(Spark Arrestor)
421A	712555		Screw -(Outlet Screen) (M4x8mm)
613	710976		Screw -(Muffler)
676	795036		DEFLECTOR, Muffler
676A	396903		DEFLECTOR, Muffler
676B	795038		Deflector-Muffler
677	794845		SCREW -(Muffler Deflector)
677A	690661		SCREW -(Muffler Deflector)
832	710586		Guard-Muffler
836	710074		Screw -(Muffler Guard) (M6x8mm)
883	711182		Gasket-Exhaust
883B	711181		Gasket-Exhaust
914A	710248		Screw -(Rocker Cover) (M6x16mm)
981	715422		Brace-Muffler
994	794945		ARRESTOR, Spark
1057	710585		Screen-Outlet
1177	710081		Nut -(Muffler)
1222	711183		Screw -(Exhaust Pipe)







## Panel Air Cleaner

REF NO	PART NO	QTY	DESCRIPTION
11	710115		Tube-Breather
53	710556		Stud -(Carburetor) (M6x100mm)
185	710068		Nut -(Air Cleaner Base)
235	710553		Shield-Fuel Spray
411	710234		Screw -(Air Cleaner Base to Air Cleaner Bracket) (M6x16mm)
445	710266		Filter-A/C Cartridge
467	710113		Knob-Air Cleaner Cover
643	710228		Retainer-Air Filter
652	710248		Screw -(Support Bracket) (M6x16mm)
875	710551		Base-Air Cleaner
890	710554		Bracket-Support -(Air Cleaner)
967	710268		Filter-Pre Cleaner
968	710552		Cover-Air Cleaner

Not For  
Reproduction






## *Panel Air Cleaner*

---

REF NO	PART NO	QTY	DESCRIPTION
163B	712535		Gasket-Air Cleaner
185	710068		Nut -(Air Cleaner Base)

---

Not For  
Reproduction



652A








## Panel Air Cleaner

---

REF NO	PART NO	QTY	DESCRIPTION
185	710068		Nut -(Air Cleaner Base)

---









Not For  
Reproduction



## *Piston/Ring, Crankshaft, Camshaft, Connecting Rod*

REF NO	PART NO	QTY	DESCRIPTION
16E	712538		Crankshaft
25A	712563		Piston Assembly -(.020" Oversize)
25A	712541		Piston Assembly -(Standard)
29	716524		Rod-Connecting
46A	712540		Camshaft
377B	712539		Key-Woodruff
741A	712203		Gear-Timing

Not For  
Reproduction





## *Piston/Ring, Crankshafts, Connecting Rod*

REF NO	PART NO	QTY	DESCRIPTION
26	715346		Ring Set -(Standard)
26	715368		Ring Set -(.020" Oversize)
27	691792		Lock-Piston Pin
28	712124		Pin-Piston
29	716524		Rod-Connecting
32	710221		Screw -(Connecting Rod)
101	710547		Pin-Shaft -(Camshaft)
377B	712539		Key-Woodruff
742	710548		Retainer-E Ring -(Camshaft)

Not For  
Reproduction



*Replacement Engine*

---

REF NO	PART NO	QTY	DESCRIPTION
--------	---------	-----	-------------

---










Not For  
Reproduction



## Rewind Starters

REF NO	PART NO	QTY	DESCRIPTION
55	691568		Housing-Rewind Starter
56	692085		Pulley-Starter
57	692086		Spring-Rewind Starter
58	66574		Rope-Starter -(Cut To Required Length)
59	805957		Insert-Grip
60	808167		Grip-Starter Rope
65	710074		Screw -(Rewind Starter) (M6x8mm)
456	691529		Plate-Pawl Friction
459	808166		Pawl-Ratchet
515	691528		Spring-Pawl
597	690876		Screw -(Pawl Friction Plate)
608	692102		Starter-Rewind
773A	690875		Retainer -(Rewind Starter)

Not For  
Reproduction



## ***Springs, Control Brackets, Electro Magnet***

REF NO	PART NO	QTY	DESCRIPTION
129	715024		Screw/Spring-Governor Speed
129A	715170		Screw/Spring-Governor Speed
188	710057		Screw -(Control Bracket)
212	710562		Link-Throttle
213A	715347		Bracket-Choke Control
222	715025		Bracket-Control
232	710563		Spring-Governor Link
380	710081		Nut -(Electro Magnet)
419	710475		Spring-Return
485	692295		Knob-Control -(Control Bracket)
742A	710477		Retainer-E Ring -(Control Bracket)
752	710478		Screw -(Link Retainer)
1012	710855		Retainer-Link
1043	692955		Magnet-Electro

Not For  
Reproduction

